

avidsen



GUARANTEE



SUPPORT
CALL

HomeCam WR

WIFI IP CAMERA

Ref.127052

EN



AvidsenHome



www.avidsen.com

TABLE OF CONTENTS



A - SAFETY INSTRUCTIONS

1 - OPERATING PRECAUTIONS	04
2 - MAINTENANCE AND CLEANING	04
3 - RECYCLING	04

B - PRODUCT DESCRIPTION

1 - KIT CONTENTS	05
2 - CAMERA	05

C - INSTALLATION

1 - OPERATION	06
2 - INSTALLING THE CAMERA	06
3 - INSTALLING THE MICRO SD CARD	06
4 - INSTALLING THE MOBILE APP AND CREATING AN ACCOUNT	06
5 - CONNECTING THE CAMERA	08
5.1 - By QR code	08
5.2 - Other method	10
6 - RESETTING THE CAMERA	12

D - USING THE PRODUCT

1 - USING THE HOMECAM WR	13
2 - BASIC SETTINGS	13
3 - USING THE ALARMS	14
3.1 - Motion detection alert	14
4 - SETTINGS FOR RECORDINGS	14
4.1 - Recording with a micro SD card	14
5 - BENEFIT AND USE OF PARTS IN THE AVIDSEN HOME APP	15
5.1 - Creating a family	15
6 - USING THE PRODUCT WITH GOOGLE HOME	16
6.1 - If you have an Android smartphone with Google Assistant	17
6.2 - If you have an Android smartphone without Google Assistant or an iPhone	17
7 - USING THE PRODUCT WITH AMAZON ALEXA	18
8 - SCENARIO AND AUTOMATION	19
8.1 - Triggering a set of actions (scenario)	19
8.1.1 - Programming the "I'm going" scenario	20
8.2 - Creating an automation	21
8.2.1 - Programming the "Living room lighting" automation	24



E - FAQ

F - TECHNICAL AND LEGAL INFORMATION

1 - TECHNICAL CHARACTERISTICS	30
2 - WARRANTY	30
3 - HELP AND ADVICE	31
4 - DECLARATION OF CONFORMITY	31

A - SAFETY INSTRUCTIONS

1 - OPERATING PRECAUTIONS

- The cameras must not be installed where the lens filter may be vulnerable to scratching and dirt.
- Do not expose the lens to direct sunlight or any reflected light source.
- Do not daisy-chain extension cords and/or multi-socket adapters.
- Do not install near acidic chemicals, ammonia or sources of toxic gases.
- The installation and use of the camera must comply with local laws.

2 - MAINTENANCE AND CLEANING

- Always unplug the product from the mains before carrying out any maintenance.
- Never use abrasive or corrosive substances to clean the products.
- Use a soft, slightly damp cloth.
- Never use an aerosol to spray the product as this may damage the internal workings.


3 - RECYCLING



This logo indicates that devices which are no longer in use must not be disposed of as household waste. They are likely to contain hazardous substances that are dangerous to both  health and the environment. Return the equipment to your local distributor or use the recycling collection service provided by your local council.



1 - KIT CONTENTS



1 x1



2 x1



3 x1



4 x3





5 x3

1	Camera
2	230 VAC/12 VDC mains adaptor

3	Antenna
4	Wall plugs
5	Mounting screw

2 - CAMERA



1	Slot cover for microSD card (not included) of up to 128GB
2	Loudspeaker grid
3	Connector for included antenna
4	Adjustable stand

5	Mains adaptor power supply
6	Reset button: resets
7	Camera lens
8	Infra-red light for night vision
9	Microphone location


C - INSTALLATION

1 - OPERATION

This camera will allow you to monitor your home and will alert you directly on your smartphone if motion is detected. You can also make photo and video recordings with this device using a micro SD card (not included).



2 - INSTALLING THE CAMERA

First plug the camera into an electrical outlet. The camera will then play a melody. The camera is awaiting connection.



3 - INSTALLING THE MICRO SD CARD

Your camera has a micro SD card slot, which gives it an internal storage memory. The maximum size is 128 GB. This card is optional, but required if you wish the camera to record independently.



4 - INSTALLING THE MOBILE APP AND CREATING AN ACCOUNT

Once the camera is connected, follow the instructions below to pair it. Download the Avidsen Home app from the Play Store or App store.




Launch the app and log in if you already have an account. If not, press **CREER UN NOUVEAU COMPTE (CREATE A NEW ACCOUNT)** and let the application guide you.



After accepting the privacy policy, you can create an account with an **email address** or with a **phone number**. Choose the method that suits you; however, we recommend that you create your account with an email address.



Procedure by email



Procedure by phone



In both cases, choose your country and then, after entering your email address or phone number, select **Obtenir le code de vérification** (Get verification code).




In a few seconds, you will receive a validation code in your email inbox or by SMS. Enter this code to finalise registration.

Note that this email may go into your spam folder.

C - INSTALLATION

If you do not receive a code before the countdown has ended, press **renvoyer** (return) and check the email address or telephone number entered.



To complete your registration, set a password between 6 and 20 characters long with letters and numbers only, then press **Terminé (Finish)**.

5 - CONNECTING THE CAMERA

If you have more than one item to pair (plugs, cameras, other bulbs) switch on only one item at a time.

The following information may vary depending on the app updates.

IMPORTANT: This device is compatible with 2.4 GHz - WPA/WPA2 networks. Not compatible with 5 GHz WiFi or with WEP encryption. Please check the WiFi settings of your router or contact your Internet service provider if you experience connection difficulties.


A message may also appear during installation indicating that the WiFi password and SSID is too long. Make sure that your box password and SSID are less than 20 characters long. Otherwise, see Chapter "5.2 Other method."

5.1 By QR code.

To start the installation, press **AJOUTER (ADD)**. Make sure your phone is connected to your router's 2.4 GHz WiFi network.



Select the product that you wish to pair and select the **HomeCam** camera.



Check that the camera indicator light is flashing red; otherwise, see the chapter **Resetting the camera**. Then press **ETAPE SUIVANTE (NEXT STEP)**.




Select your 2.4 GHz WiFi network (**note:** your smartphone must be connected to the WiFi network to which the camera will be connected), enter your network password and press **CONFIRMER (CONFIRM)**




After pressing **continuer (continue)**, a QR code will be displayed on your screen. Place your smartphone screen **10-15 cm** in front of the camera lens. It will then start to beep. Then press **J'ai entendu le bip (I heard the beep)**.

If this fails, check that the lens is clean and clear (protective film removed) and then repeat the step.






Please wait while the connection procedure takes place. This step can take several minutes.



Your Avidsen HomeCam has been successfully paired. You can set a name by tapping the pencil and pressing **TERMINE (FINISH)**.



Your camera is now operational and will appear in your app. The camera indicator light will then be solid blue.


5.2 Other method.

If you are unable to install your camera with the QR code or the password and SSID of your box are more than 20 characters long, follow the procedure indicated below:

After you have passed the product selection step, press **Autre méthode (Other method)** at the top right of the screen.



Then select **Configuration intelligente (Smart configuration)**.






Wait for it to connect:

Now press **étape suivante (next step)**.



Select your 2.4 GHz WiFi network (**note:** your smartphone must be connected to the WiFi network to which the camera will be connected), enter your network password and press **CONFIRMER (CONFIRM)**.


Your camera is now operational and will appear in your app. The camera indicator light will then be solid blue.



6 - RESETTING THE CAMERA

The following instructions may help you if you have any problems during the pairing procedure:


To **reset** the camera, press the RESET button for 15 seconds. The camera will play a melody to confirm that the operation was successful.



The camera also needs to be deleted from the mobile app. To do this, tap the pencil at the top right of your screen.

Once in the **détails de l'appareil (device details)**, scroll down to the bottom of the interface and select **enlevez l'appareil (remove device)**.


To complete the deletion process, press **confirmer (confirm)**.



Your device has now been deleted from the app.

1 - USING THE HOMECAM WR


With the Avidsen Home app, you can control several functions on the HomeCam WR, such as photo and video recording, or even motion detection alerts.




1	Return icon
2	Device name
3	Device settings
4	Activate/deactivate the sound
5	Image quality adjustment
6	Full Screen
7	Take a photo
8	Activate/deactivate oral communication
9	Activate/deactivate video recording
10	Video recording playback interface
11	Motion detection alert settings
12	Access to the photo album (not available on IOS)

2 - BASIC SETTINGS

This part covers the basic settings on your camera. To access them, enter the paramètre (settings) menu of your camera  and then press the Réglages de fonction de base (Basic function settings) tab.



1	Enable/disable privacy mode: switches off the image and sound of the camera when you're home to only monitor when necessary
2	Access to basic camera settings
3	Access to motion detection settings




1	Enable/disable privacy mode: switches off the image and sound of the camera when you're home to only monitor when necessary
2	Default audio mode: unidirectional (the camera's sound can be heard on the smartphone) or bidirectional (the camera speaker transmits the sound of the smartphone's microphone)

3 - USING THE ALARMS


The Avidsen HomeCam WR camera alerts you in real time if motion is detected within a set time range. This alert is provided by a push notification on your smartphone screen.

3.1 - motion detection alert

To activate motion detection, go to the Paramètres (Settings) menu of your camera and then select Paramètre d'alerte de la détection (Detection alert settings).



You can then activate detection and have access to different settings:




You can activate motion detection permanently

or set an activation time range. You can also set detection sensitivity to low, medium or high.

4 - SETTINGS FOR RECORDINGS

The Avidsen HomeCam WR is designed to make recordings that can be viewed from the Avidsen Home app.

4.1 RECORDING WITHOUT AN SD CARD



You can take a screenshot or create a manual recording without a micro SD card. These items can then be viewed directly in the **Photo Album** tab.

Important: it is not possible to create a continuous recording or event recording without an SD card.

4.2 RECORDING WITH MICRO SD CARD

A micro SD card is required if you wish to create a continuous recording.

Once installed, the **Réglages de carte SD (SD card settings)** tab appears in the camera settings.

5 - BENEFIT AND USE OF PARTS IN THE AVIDSEN HOME APPLICATION

With the Avidsen Home application, you can manage different kinds of smart devices (bulb, smart plug, camera) which can be linked to a specific room in your home, for creating scenarios or organising your devices in the application. To do this, it is necessary to create a “family.”

5.1 CREATING A FAMILY

Tap the profile icon at the bottom right to access the profile settings.



You will then be able to select the recording mode:


- Event recording: triggers recording once motion or sound is detected.
- Continuous recording: the camera records continuously.



You can also fully format the micro SD card from this menu by pressing **formatage de la carte SD (format SD card)**. However, the camera will automatically delete the oldest recordings once the micro SD card is full.




Then select **GESTION DE LA FAMILLE (FAMILY MANAGEMENT)**. You can then choose a house name (required), its location (optional) and the rooms in the home.




Once your family has been configured to your liking, click on “**Terminé (Finished)**” at the top right.

The family name (“house” in this example) will then appear on the home screen with your devices.



You can then set the location of a device by going to its settings and choosing the position of the device in the home. The smart device will now appear in the selected room.



6 - USING THE PRODUCT WITH GOOGLE HOME

Note: the name you give your Avidsen Home devices is the one that will be recognised by Google Assistant. Example: if you have a bulb called “kitchen light,” the command “OK Google, turn on kitchen light” will work, but “OK Google, turn on the light in the kitchen” may not trigger any action.

Google Assistant can help you control your connected devices.

For example, you can use the following commands: “OK Google” plays the living room camera video on the Living Room TV

You must have a Chromecast (in this example, it is called “Living Room TV”)

For more information on device names or creating/linking a room, please consult Google support.

A word of advice, however. In order to avoid unwanted commands if you connect several modules in one area, we recommend that you avoid using a group name suggested by Google Home (bedroom, office, living room, etc.) when naming your command module.

In the event of problems with the Google Home application or configuration of the device in Google Home, contact Google support.


The setting up procedure depends on your smartphone and requires an Internet connection:

The following information may vary depending on updates to the Google Home app or your operating system.


6.1 IF YOU HAVE AN ANDROID SMARTPHONE WITH GOOGLE ASSISTANT

Your devices need to be paired in the Avidsen Home app to be controlled with Google Assistant. They must be connected on the same WiFi network.

- Connect devices to Google Assistant
 - On your Android phone or tablet, press and hold the home button or say "OK Google."
 - In the lower right-hand corner, press .
 - Press the **logo on the upper right** then **Paramètres (Settings)** then **Assistant** and finally **Contrôle de la maison (Control from home)**.
 - In the "Appareils (Devices)" tab, press "Ajouter des appareils (Add devices)" .
 - Select the Avidsen Home app, then follow the instructions.



- Then enter the username and password of the Avidsen Home account to authorise Google Assistant to add and interact with your Avidsen Home accessories.




Your product is now connected in Google Assistant and you can use voice control with it.


6.2 IF YOU HAVE AN ANDROID SMARTPHONE WITHOUT GOOGLE ASSISTANT OR AN IPHONE

Your devices need to be paired in the Avidsen Home app to be controlled with Google Assistant. They must be connected on the same WiFi network.

- Connect devices to Google Assistant
 - On your tablet or phone, install and start the **Google Home app** and log in to the relevant account for your Google Home speaker.
 - In the lower right-hand corner, press **Compte (Account)** .
 - Next, press **Configurer ou ajouter (Set up or add)** and then **Configurer un appareil (Set up device)**.
 - Press **Vous avez déjà configuré des appareils? (Have something already set up?)**
 - In the list that appears, press Avidsen Home



- Then enter the username and password of the Avidsen Home account to authorise Google Assistant to add and interact with your Avidsen Home accessories.



7 - USING WITH AMAZON ALEXA

Note: the name that you give your Avidsen Home devices is the one that will be recognised by Alexa. Example: if you have a bulb called “kitchen light,” the command “Alexa, turn on kitchen light” will work, but “Alexa, turn on the light in the kitchen” may not trigger any action.

The following information may vary depending on updates to the Alexa app or your operating system.

The Amazon Alexa Assistant can help you control your connected devices.

For example, you can use the following commands: “Alexa” plays the living room camera video on the Living Room Screen

You need an Echo Spot or Echo Show (in this

example, it is called “Living Room Screen”)

Download and install the Amazon Alexa app from the Play Store or Apple store.

Your devices must be paired in the Avidsen Home app to be controlled by the Amazon assistant. They must be connected on the same WiFi network.

- Installing the Avidsen Home Skill
 - In the Amazon Alexa app, press the menu at the top left and select **Skills et Jeux (Skills and Games)**
 - Search for **Avidsen Home** in the list of skills or use Recherche (Search) at the top right.
 - Select the **Avidsen Home Skill** and **activate for use**
 - Fill in the username and password for the Avidsen Home app
 - Once the skill is correctly paired, press the cross at the top left.
 - The app will offer to search for devices. Press Detect devices.
- Connect devices to Amazon Echo
 - Using the guided Search to connect an automated device
 - In the Amazon Alexa app, press the menu at the top left and select **Ajouter un appareil (Add a device)**.
 - Select the type of device you want to connect.
 - Select the brand and follow the instructions on the screen.
 - Use voice command to connect an automated device
 - Once a skill is installed, say “Alexa, find new devices.”
 - After 45 seconds, Alexa will give you the devices found.

For more information on Amazon Alexa, please consult Amazon support.

A word of advice, however. In order to avoid unwanted commands if you connect several modules in one area, we recommend that you avoid using a group name suggested by Alexa (bedroom, office, living room, etc.) when naming your command module.

In the event of a problem with the Amazon Alexa app or with setting up the device in Amazon Alexa, please contact Amazon support.

8 - SCENARIO AND AUTOMATION

Each device in the **Avidsen Home** range can be triggered and interact with other products. This way, you can create life scenarios, grouping different actions or sequences into one, or automatically trigger a device according to the status of another.

8.1 TRIGGERING A SET OF ACTIONS (SCENARIO)

The scenario system in the **Avidsen Home** app allows you to group actions that will be triggered on demand, by clicking on a single button on your smartphone.

Example: creating an “I’m going” scenario to turn off my smart plug and activate motion detection on my camera:



Click on  at the bottom of the screen, then on **Scénario (Scenario)** at the top left and, finally, on **Ajouter un scénario (Add a scenario)**:



Name your scenario, then click on  to set the actions to be executed:




1	Name your scenario here at your convenience
2	You can change the background image here
3	Set the actions to be performed by clicking here
4	If the box is checked, the scenario will be displayed alongside your products linked to the application



- | | |
|----------|--|
| 1 | Allows you to use a previously defined automation (an automatic action). See next paragraph for more details |
| 2 | Allows you to insert a pause of an adjustable time period in the performance of actions |
| 3 | Displays the list of products already linked in the app and the possible actions |

Then define each of the actions to be performed (in our example: select **Commuter (Switch)** then **Arrêt (Stop)**). To finish, press **Sauvegarder (Save)** then **Suivant (Next)**.

The **Choisissez votre automatisation (Choose your automation)** function allows you to call on an automation that has already been saved and enable or disable it while the new scenario is running.




8.1.1 PROGRAMMING THE "I'M GOING" scenario

The scenario in this example will allow the user to activate motion detection on their camera and turn off a smart plug just by clicking on a single icon in the app.

After following the previous steps, click on **"Appareil"** (**"Device"**) to access the list of possible actions for each device that you wish to trigger with your scenario. In this example, Avidsen HomePlug is selected.

Repeat the step, selecting the HomeCam this time, then **Motion Alert** and **On**. To finish, press **Sauvegarder (Save)** then **Suivant (Next)**.

D - USING THE PRODUCT



The actions for the camera and the plug will then appear in the scenario list. You will then have to press **Sauvegarder (Save)** at the top right to complete the scenario.



If you wish to access the details or delete it, click on the “...” icon at the top right of its name.

The scenario you have just created will appear on the list on the **Scénario (Scenario)** tab of the app.

If you checked the “Apparaît sur la première page”

(“Display on the first page”) box, the scenario created will also appear alongside your products on the **Ma famille (My family)** screen.

Just click on the **Exécuter (Execute)** button to launch the entire sequence that you have programmed in your scenario.

8.2 - CREATING AN AUTOMATION

The automation system in the **Avidsen Home** app allows you to group devices and actions which will be triggered automatically by the action of another device or a condition (temperature, time, etc.) .

Example: creating a “Living room lighting” automatic action that turns on the light for a few seconds when a movement is detected by the camera:

Click on **Scénario** then on **Automatisation (Automation)** at the top right and finally on **Ajouter une action automatique (Add automatic action):**



D - USING THE PRODUCT



1	Go back
2	Save automation
3	Change the name as you wish
4	You can change the background image if you wish
5	Selection of condition type
6	Selection of conditions to be met for actions to be executed
7	Selection of actions to be executed
8	Selection of the automation validity time slot (e.g. only at night)

• **Quand toutes les conditions sont réunies (When all the conditions are met)** corresponds to an "ET" ("AND") function:

- If Temperature = x **ET (AND)** time = y **ET (AND)** device = n then...


• **Lorsque l'une des conditions est remplie (When one of the conditions is met)** corresponds to a "OU" ("OR") function:

- If Temperature = x **OU (OR)** time = y **OU (OR)** device = n then...

After selecting the condition type, choose the conditions themselves:





One of the most important settings is the selection of the **type de condition (condition type)**. This allows automation to deal with multiple conditions.



1	Set a temperature weather condition*
2	Set a humidity weather condition*
3	Set a weather condition*
4	Set a sunrise or sunset condition*
5	Set a wind condition*
6	Set a time condition
7	Set a condition from a device already linked to the application



*These conditions take into account the geolocation of your smartphone to access weather data.

The following part is related to the actions that will be triggered by the conditions:





1	Allows you to use a previously defined Scenario (set of actions).
2	Allows you to use a previously defined automation (an automatic action)
3	Allows you to send a notification to the smartphone when automation is active
4	Allows you to insert a pause of an adjustable time period in the performance of actions
5	Set an action on a device already recorded in the app

The last setting allows you to define a time slot during the day, if necessary, during which to authorise the automation launch:



D - USING THE PRODUCT


Once all these settings have been confirmed, you can save your automation at the top right





8.2.1 PROGRAMMING THE "LIVING ROOM LIGHTING" AUTOMATION

The automatic action in this example will allow the user to turn on the bulb at night as soon as motion is detected by the camera and the lamp is already off. After a minute, the lamp will turn off until the next detection.

First, select the condition type. In this example, all of our conditions must be active to turn the bulb on. So select **quand toutes les conditons sont réunies (when all the conditons are met)**.




• FOR THE CAMERA




Then select the conditions. In our case, we need one motion detection condition and another for the lamp to be off.


• FOR THE BULB




Under these conditions, the actions will start if motion is detected in the camera's visual field **ET** (AND) if the bulb is off:




Now, set the actions that will be carried out:




To turn on the bulb:







Then add a **“retard”** (“delay”) that will trigger the next action after the desired time period:





Then add the last action, turn off the lamp in this example:



After these steps, you will have 3 actions: turn on the bulb, wait one minute and turn off the bulb:




Finally, you can choose an automation validity period, in this case at night:



The automation is now complete. You can save it at the top right:

If you wish to access the details or delete it, click on the “...” icon at the top right of its name.



Symptoms	Possible causes	Solutions
<i>Unable to install the Avidsen Home app on my Android device</i>	Your device has an outdated or incompatible version of Android	Please contact the technical support of the manufacturer of your Android device to get a recent update.
	GooglePlay checks that you have all the essential items for the proper operation of the app. If your device does not meet all required criteria, you will be unable to install it.	Try the installation on a different Android device.
<i>Unable to install the Avidsen Home app on my Apple device</i>	The version of iOS on your device is not up to date	Update the operating system on your device.
	Your device is not supported	Avidsen Home is compatible from version IOS 9
<i>The app freezes or there are bugs</i>	You experience problems configuring the app or accessing your camera(s)	Please uninstall the application and reset your camera(s). Then add your camera(s).
<i>Configuration of your camera using WiFi from your smartphone failed</i>	Connection to the camera is too slow or the device is too far from the internet hub	Move the camera and smartphone closer to the box/modem/router.
	The smartphone/tablet are linked to an incompatible WiFi network	Please ensure that your smartphone is linked to a 2.4GHz network
<i>Cannot connect to camera over a 3G or 4G Internet link but it works when connected to a local network</i>	Network configuration problem	Check your device settings (box, router, firewall)
	Incorrect video settings	Check the video settings and reduce the quality if necessary
	Your home Internet speed is insufficient to support the connection from your smartphone	Check that the available bandwidth exceeds 1Mbps per second (upload and download) for low-quality display; or that it exceeds 2Mbps per second for HD
<i>Poor quality or shaky image</i>	Incorrect video settings	Check the video settings and reduce/increase the quality if necessary

<i>Movement detection is triggered unnecessarily</i>	Unsuitable movement detection settings	Reduce the sensitivity of detection
<i>When movement is detected, no Push alert is received</i>	Unsuitable movement detection settings	Please check the configuration of the camera, the enabled alerts and the motion sensitivity
	The application is not authorised to send a Push alert	Please check your Avidsen Home rights within your iOS application Security and Privacy settings or Android application settings
<i>PUSH Notifications only work when the app is displayed on the Android screen</i>	Avidsen Home is not allowed to run in the background, or has been completely closed	Please restart Avidsen Home. Make sure that no other management or power saving application automatically closes the application in the background.
	Your Android device has reached the maximum limit of applications launched simultaneously	Close the applications or increase the limit of simultaneous applications in your device settings.
<i>Pairing issues</i>	The camera is already paired with another user account.	Reset the camera. It will be automatically deleted from the old account.

1 - TECHNICAL CHARACTERISTICS

Resolution	2M Pixels
Technical characteristics	Power supply: 12V/1A Real-time video playback Communication protocol: WiFi b/g/n 2.4GHz Encryption: WPA-PSK/WPA2 Viewing angle: 68°
Audio	Two-way
Night vision	Yes, 25m range
Sensor and lens	1/4" CMOS
Shutter speed and compression	1/25 – 1/100,000 per second - H264
Storage	Yes, on SD card (128GB max, not included)
Average	10.8W Max DC 12V, 1A
Operating temperature	-20°C +55°C
Dimensions and weight	67mm x 57mm x 158mm – 286g

2 - WARRANTY

- This product is guaranteed for parts and labour for 2 years from the date of purchase. Proof of purchase must be retained for the duration of the warranty period.
- The warranty does not cover damage caused by negligence, knocks or accidents. The parts of this product must not be opened or repaired by any persons not employed by Avidsen. The warranty will be void if the device is tampered with.
- Avidsen undertakes to keep a stock of spare parts for this product throughout the contractual warranty period.

3 - HELP AND SUGGESTIONS

- If, despite the care we have taken in designing our products and drafting these instructions, you do encounter difficulties when installing your product or you have any questions, we strongly recommend that you contact one of our specialists who will be glad to help.
- If you encounter operating problems during the installation or a few days afterwards, it is essential for you to be in front of your installation when contacting us, so that one of our technicians can diagnose the source of the problem, as it will probably be the result of a setting that is incorrect or an installation that is not to specification. If the problem is caused by the product itself, the technician will give you an RMA number so that you can return the unit to the shop.
Without this RMA number, the shop may refuse to exchange your product.

Contact our after sales service team technicians:

0 892 701 369 Service 0,35 €/min
+ prix appel

Monday to Friday, 9pm to 12pm, and 2pm to 6pm.

Avidsen undertakes to keep a stock of spare parts for this product throughout the contractual warranty period.



Need some help?
Avidssy
 will answer your questions
 at www.avidsen.com
 (toll-free, 24/7)

4 - DECLARATION OF CONFORMITY

Avidsen hereby declares that the equipment designated below:
 Avidsen HomeCam WR reference 127052
 complies with the RED 2014/53/EU directive and that its conformity has been assessed pursuant to applicable standards:

Directive 2014/35/EU: (protection of users' health and safety)

- EN 62479:2010
- EN 62368-1:2014 + A11:2017
- EN 50663:2017

Directive 2014/30/EU: (protection requirements relating to electromagnetic compatibility).

- EN 301 489-1 V2.2.3
- EN 301 489-17 V3.2.3
- EN 55032:2015
- EN 55035:2017
- EN 61000-3-2:2019
- EN 61000-3-3:2013 +A1:2019

Directive 2014/53/EU: (efficient use of the radio spectrum, in order to avoid harmful interference).

- EN 300 328 V2.2.2

Tours, 19/10/2020
 Alexandre Chaverot, CEO





aidsen

Aidsen
19 avenue Marcel Dassault - ZAC des Deux Lions
37200 Tours - France