



Betriebsanleitung PKW Auffahrrampe



Name oder Adresse des Herstellers:
 MTS MarkenTechnikService GmbH & Co. KG
 Carl-Benz-Str. 2
 76761 Rülzheim – Germany

Angaben zur bestimmungsgemäßen Verwendung:

- Lesen Sie diese Bedienungsanleitung vollständig durch und bewahren Sie diese zu Nachschlagezwecken auf.
- Zulässige Reifenbreite: 195 mm.
- Maximale Tragfähigkeit pro Paar Auffahrrampen: 2000 kg.

Sicherheitshinweise:

- Die Auffahrrampen dürfen nicht über die vom Hersteller vorgegebene Nennlast belastet werden.
- Nur paarweise verwenden, parallel aufstellen.
- Auf festen, ebenen Untergrund achten.
- Auffahrrampe gegen rückwärtiges Wegrutschen sichern.
- Auffahren nur unter Aufsicht einer zweiten Person.
- Vorsichtige Fahrweise einhalten.
- Fahrzeug gegen Wegrollen sichern.

Wartung und Pflege:

- Vor jeder Verwendung auf Beschädigung prüfen.
- Beschädigte Auffahrrampen nicht mehr verwenden.
- Halten Sie die Auffahrflächen frei von Verunreinigungen durch Fett und Öl.
- Stark korrodierte Auffahrrampen nicht mehr verwenden.

Anleitung für eine sichere Aufstellung und Gebrauch



1. Die Auffahrt auf die
Auffahrrampen



2. Position bei der Anwendung
der Auffahrrampen



Car Ramp Operating Instructions



Name or address of the manufacturer:
 MTS MarkenTechnikService GmbH & Co. KG
 Carl-Benz-Str. 2
 76761 Rülzheim – Germany

Information about intended use:

- Please read the entire operating instructions and keep for future reference.
- Permissible tyre width: 195 mm.
- Maximum load rating per set of car ramps: 2000 kg.

Safety notices:

- Never exceed the weight rating of the car ramps specified by the manufacturer.
- Always use in pairs, placed parallel.
- Ensure the ground is solid and level.
- Secure the back of the ramps to prevent them from slipping.
- Only use under the supervision of a second person.
- Drive carefully.
- Secure the vehicle from rolling away.

Maintenance and care:

- Check for damages before every use.
- Do not use the ramps if damaged.
- Keep the ramps free from contamination by grease and oil.
- Do not use heavily corroded ramps.

Instructions for safe set-up and use



1. Driving up the ramps



2. Position for using the ramps