




Method 1 Directly on the wall

Mounting adhesive: Apply the adhesive to the panel and place it against the wall. Ensure it is firmly pressed.

Screws: Screw the panel through the felt and into the wall. We recommend using 18 screws per panel. Remember to use wall plugs if your wall type requires it.

Method 2 On a batten

For optimal sound absorption, set up a batten with 45 mm (1.77 in) battens on your wall. We recommend a spacing of 500 mm c/c (19.69 in c/c) between your battens. Insert mineral wool between the battens. Screw the panel onto the battens through the felt.

Panel adaptation: If you need to customize the panels in width or length, we recommend using a plunge saw or circular saw for cutting.